

Sound comes out of my PC/Mac or the built-in speaker of my smartphone incorrectly.

Please check in the following order:

1. Confirm Split Output

Tap the djay icon > Gear icon on the top of the window, and turn on the [Split Output] in [PRE-CUEING].



2. Adjust the speaker volume

1. Minimize the volume level of the PC/Mac or smartphone.
2. Play a track.
3. Move the DDJ-200 channel fader to the top.
4. Move the crossfader of the DDJ-200 to the center.
5. Increase the volume level of the PC/Mac or smartphone little by little.
6. Adjust the volume for the power speakers until you have a volume level you're happy with.

3. Adjust headphone volume

Tap djay icon > Gear icon on the top of the screen, and move the slider in [PRE-CUEING] to adjust the volume level.

djay For iOS



djay for Android

