

DJM-900NXS2 SEND/RETURN function

CONNECTION



If a cable is connected to a Send/Return or USB-A terminal, the Send/Return On/Off button is lit blue, which is a sign that you can turn on and off SEND/RETURN.

[RETURN TYPE] SWITCH

If you change the return type, Send/Return On/Off is disabled automatically.

RETURN TYPE : INSERT

You can adjust the RETURN level by turning the Send/Return level knob. The audio level returning from an external effector or an iOS device can be adjusted.



RETURN TYPE : AUX

You can adjust the SEND level by turning the Send/Return level knob. The audio level sending to an external effector or an iOS device can be adjusted.

