

XDJ-R1 Operating Instructions Errata

We apologize for the following errors in the Operating Instructions. Please note the following corrections.

page	Error	Correction																																																																																																																																																																																																																																																																																																																																																						
24	<p>List of WLAN INFORMATION items</p> <p>When [MODE] at [WLAN SETTING] is set to [OFF], only [MODE] and [MAC ADDRESS] are displayed.</p>	<p>List of WLAN INFORMATION items</p> <p>When [MODE] at [WLAN SETTING] is set to [DISABLE], only [MODE] and [MAC ADDRESS] are displayed.</p>																																																																																																																																																																																																																																																																																																																																																						
25	<p>List of WLAN SETTING items</p> <p>When [MODE] at [WLAN SETTING] is set to [OFF], only [MODE] and [RESET TO DEFAULT] are displayed.</p>	<p>List of WLAN SETTING items</p> <p>When [MODE] at [WLAN SETTING] is set to [DISABLE], only [MODE] and [RESET TO DEFAULT] are displayed.</p>																																																																																																																																																																																																																																																																																																																																																						
28	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">Rotary selector (SELECT PUSH) (turn)</td> <td style="width: 5%;">Bn</td> <td style="width: 5%;">64</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">Bn</td> <td style="width: 5%;">65</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">Difference count value from when previously operated - Turn clockwise: 1 ~ (max) 30 - Turn counterclockwise: 127 ~ (min) 98</td> </tr> </table>	Rotary selector (SELECT PUSH) (turn)	Bn	64	dd	Bn	65	dd	Difference count value from when previously operated - Turn clockwise: 1 ~ (max) 30 - Turn counterclockwise: 127 ~ (min) 98	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">Rotary selector (SELECT PUSH) (turn)</td> <td style="width: 5%;">Bn</td> <td style="width: 5%;">64</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">Bn</td> <td style="width: 5%;">65</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">Difference count value from when previously operated - Turn clockwise: 1 - Turn counterclockwise: 127</td> </tr> </table>	Rotary selector (SELECT PUSH) (turn)	Bn	64	dd	Bn	65	dd	Difference count value from when previously operated - Turn clockwise: 1 - Turn counterclockwise: 127																																																																																																																																																																																																																																																																																																																																						
Rotary selector (SELECT PUSH) (turn)	Bn	64	dd	Bn	65	dd	Difference count value from when previously operated - Turn clockwise: 1 ~ (max) 30 - Turn counterclockwise: 127 ~ (min) 98																																																																																																																																																																																																																																																																																																																																																	
Rotary selector (SELECT PUSH) (turn)	Bn	64	dd	Bn	65	dd	Difference count value from when previously operated - Turn clockwise: 1 - Turn counterclockwise: 127																																																																																																																																																																																																																																																																																																																																																	
28	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">MODE (HOT CUE/4BEAT SAMPLER) button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">59</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">60</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">OFF=0, ON=127</td> </tr> </table>	MODE (HOT CUE/4BEAT SAMPLER) button	9n	59	dd	9n	60	dd	OFF=0, ON=127	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">MODE (HOT CUE/4BEAT SAMPLER) button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">59</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">60</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">HOT CUE will be selected=0, if 0 is already received. SAMPLER will be selected=127, if 127 is already received.</td> </tr> </table>	MODE (HOT CUE/4BEAT SAMPLER) button	9n	59	dd	9n	60	dd	HOT CUE will be selected=0, if 0 is already received. SAMPLER will be selected=127, if 127 is already received.																																																																																																																																																																																																																																																																																																																																						
MODE (HOT CUE/4BEAT SAMPLER) button	9n	59	dd	9n	60	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
MODE (HOT CUE/4BEAT SAMPLER) button	9n	59	dd	9n	60	dd	HOT CUE will be selected=0, if 0 is already received. SAMPLER will be selected=127, if 127 is already received.																																																																																																																																																																																																																																																																																																																																																	
28	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">4BEAT SAMPLER A button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">50</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">99</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">OFF=0, ON=127</td> </tr> <tr> <td>4BEAT SAMPLER B button</td> <td>9n</td> <td>51</td> <td>dd</td> <td>9n</td> <td>100</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> <tr> <td>4BEAT SAMPLER C button</td> <td>9n</td> <td>52</td> <td>dd</td> <td>9n</td> <td>101</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> </table>	4BEAT SAMPLER A button	9n	50	dd	9n	99	dd	OFF=0, ON=127	4BEAT SAMPLER B button	9n	51	dd	9n	100	dd	OFF=0, ON=127	4BEAT SAMPLER C button	9n	52	dd	9n	101	dd	OFF=0, ON=127	<p>delete</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">4BEAT-SAMPLER-A-button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">50</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">99</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">OFF=0, ON=127</td> </tr> <tr> <td>4BEAT-SAMPLER-B-button</td> <td>9n</td> <td>51</td> <td>dd</td> <td>9n</td> <td>100</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> <tr> <td>4BEAT-SAMPLER-C-button</td> <td>9n</td> <td>52</td> <td>dd</td> <td>9n</td> <td>101</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> </table>	4BEAT-SAMPLER-A-button	9n	50	dd	9n	99	dd	OFF=0, ON=127	4BEAT-SAMPLER-B-button	9n	51	dd	9n	100	dd	OFF=0, ON=127	4BEAT-SAMPLER-C-button	9n	52	dd	9n	101	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																						
4BEAT SAMPLER A button	9n	50	dd	9n	99	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT SAMPLER B button	9n	51	dd	9n	100	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT SAMPLER C button	9n	52	dd	9n	101	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-A-button	9n	50	dd	9n	99	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-B-button	9n	51	dd	9n	100	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-C-button	9n	52	dd	9n	101	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
29	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">4BEAT SAMPLER A button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">50</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">99</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">Off=0, lit=127</td> </tr> <tr> <td>4BEAT SAMPLER B button</td> <td>9n</td> <td>51</td> <td>dd</td> <td>9n</td> <td>100</td> <td>dd</td> <td>Off=0, lit=127</td> </tr> <tr> <td>4BEAT SAMPLER C button</td> <td>9n</td> <td>52</td> <td>dd</td> <td>9n</td> <td>101</td> <td>dd</td> <td>Off=0, lit=127</td> </tr> </table>	4BEAT SAMPLER A button	9n	50	dd	9n	99	dd	Off=0, lit=127	4BEAT SAMPLER B button	9n	51	dd	9n	100	dd	Off=0, lit=127	4BEAT SAMPLER C button	9n	52	dd	9n	101	dd	Off=0, lit=127	<p>delete</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">4BEAT-SAMPLER-A-button</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">50</td> <td style="width: 5%;">dd</td> <td style="width: 5%;">9n</td> <td style="width: 5%;">99</td> <td style="width: 5%;">dd</td> <td style="width: 20%;">Off=0, lit=127</td> </tr> <tr> <td>4BEAT-SAMPLER-B-button</td> <td>9n</td> <td>51</td> <td>dd</td> <td>9n</td> <td>100</td> <td>dd</td> <td>Off=0, lit=127</td> </tr> <tr> <td>4BEAT-SAMPLER-C-button</td> <td>9n</td> <td>52</td> <td>dd</td> <td>9n</td> <td>101</td> <td>dd</td> <td>Off=0, lit=127</td> </tr> </table>	4BEAT-SAMPLER-A-button	9n	50	dd	9n	99	dd	Off=0, lit=127	4BEAT-SAMPLER-B-button	9n	51	dd	9n	100	dd	Off=0, lit=127	4BEAT-SAMPLER-C-button	9n	52	dd	9n	101	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																						
4BEAT SAMPLER A button	9n	50	dd	9n	99	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT SAMPLER B button	9n	51	dd	9n	100	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT SAMPLER C button	9n	52	dd	9n	101	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-A-button	9n	50	dd	9n	99	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-B-button	9n	51	dd	9n	100	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
4BEAT-SAMPLER-C-button	9n	52	dd	9n	101	dd	Off=0, lit=127																																																																																																																																																																																																																																																																																																																																																	
30	<p>2 Mixer</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">SW Name</th> <th colspan="2">MIDI message (this unit to computer)</th> <th rowspan="2">Remarks (dd values)</th> </tr> <tr> <th>When SHIFT button is off</th> <th>When SHIFT button is on</th> </tr> </thead> <tbody> <tr> <td rowspan="2">MASTER LEVEL control</td> <td>B6 0 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 32 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">MIC LEVEL control</td> <td>B6 20 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 52 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">MIC EQ control</td> <td>B6 22 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 54 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">AUX LEVEL control</td> <td>B6 24 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 56 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">BOOTH MONITOR control</td> <td>B6 26 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 58 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="8">TRIM control</td> <td rowspan="2">Deck A</td> <td>B6 3 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 35 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 4 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 36 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 5 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 37 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 6 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 38 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">HEAD PHONES MIXING control</td> <td>B6 1 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 33 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">HEAD PHONES LEVEL control</td> <td>B6 2 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 34 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="8">EQ [HI] control</td> <td rowspan="2">Deck A</td> <td>B6 7 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 39 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 8 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 40 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 9 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 41 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 10 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 42 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="8">EQ [MID] control</td> <td rowspan="2">Deck A</td> <td>B6 11 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 43 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 12 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 44 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 13 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 45 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 14 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 46 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="8">EQ [LOW] control</td> <td rowspan="2">Deck A</td> <td>B6 15 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 47 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 16 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 48 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 17 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 49 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 18 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 50 LSB</td> <td>- - -</td> <td></td> </tr> </tbody> </table>	SW Name	MIDI message (this unit to computer)		Remarks (dd values)	When SHIFT button is off	When SHIFT button is on	MASTER LEVEL control	B6 0 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 32 LSB	- - -		MIC LEVEL control	B6 20 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 52 LSB	- - -		MIC EQ control	B6 22 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 54 LSB	- - -		AUX LEVEL control	B6 24 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 56 LSB	- - -		BOOTH MONITOR control	B6 26 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 58 LSB	- - -		TRIM control	Deck A	B6 3 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 35 LSB	- - -		Deck B	B6 4 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 36 LSB	- - -		Deck C	B6 5 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 37 LSB	- - -		Deck D	B6 6 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 38 LSB	- - -		HEAD PHONES MIXING control	B6 1 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 33 LSB	- - -		HEAD PHONES LEVEL control	B6 2 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 34 LSB	- - -		EQ [HI] control	Deck A	B6 7 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 39 LSB	- - -		Deck B	B6 8 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 40 LSB	- - -		Deck C	B6 9 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 41 LSB	- - -		Deck D	B6 10 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 42 LSB	- - -		EQ [MID] control	Deck A	B6 11 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 43 LSB	- - -		Deck B	B6 12 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 44 LSB	- - -		Deck C	B6 13 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 45 LSB	- - -		Deck D	B6 14 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 46 LSB	- - -		EQ [LOW] control	Deck A	B6 15 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 47 LSB	- - -		Deck B	B6 16 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 48 LSB	- - -		Deck C	B6 17 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 49 LSB	- - -		Deck D	B6 18 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 50 LSB	- - -		<p>2 Mixer</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">SW Name</th> <th colspan="2">MIDI message (this unit to computer)</th> <th rowspan="2">Remarks (dd values)</th> </tr> <tr> <th>When SHIFT button is off</th> <th>When SHIFT button is on</th> </tr> </thead> <tbody> <tr> <td rowspan="2">MASTER LEVEL control</td> <td>B6 0 MSB</td> <td>B6 0 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 32 LSB</td> <td>B6 32 LSB</td> <td></td> </tr> <tr> <td rowspan="2">MIC LEVEL control</td> <td>B6 20 MSB</td> <td>B6 20 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 52 LSB</td> <td>B6 52 LSB</td> <td></td> </tr> <tr> <td rowspan="2">MIC EQ control</td> <td>B6 22 MSB</td> <td>B6 22 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 54 LSB</td> <td>B6 54 LSB</td> <td></td> </tr> <tr> <td rowspan="2">AUX LEVEL control</td> <td>B6 24 MSB</td> <td>B6 24 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 56 LSB</td> <td>B6 56 LSB</td> <td></td> </tr> <tr> <td rowspan="2">BOOTH MONITOR control</td> <td>B6 26 MSB</td> <td>B6 26 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 58 LSB</td> <td>B6 58 LSB</td> <td></td> </tr> <tr> <td rowspan="8">TRIM control</td> <td rowspan="2">Deck A</td> <td>B6 3 MSB</td> <td>B6 3 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 35 LSB</td> <td>B6 35 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 4 MSB</td> <td>B6 4 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 36 LSB</td> <td>B6 36 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 5 MSB</td> <td>B6 5 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 37 LSB</td> <td>B6 37 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 6 MSB</td> <td>B6 6 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 38 LSB</td> <td>B6 38 LSB</td> <td></td> </tr> <tr> <td rowspan="2">HEAD PHONES MIXING control</td> <td>B6 1 MSB</td> <td>B6 1 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 33 LSB</td> <td>B6 33 LSB</td> <td></td> </tr> <tr> <td rowspan="2">HEAD PHONES LEVEL control</td> <td>B6 2 MSB</td> <td>B6 2 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 34 LSB</td> <td>B6 34 LSB</td> <td></td> </tr> <tr> <td rowspan="8">EQ [HI] control</td> <td rowspan="2">Deck A</td> <td>B6 7 MSB</td> <td>B6 7 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 39 LSB</td> <td>B6 39 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 8 MSB</td> <td>B6 8 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 40 LSB</td> <td>B6 40 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 9 MSB</td> <td>B6 9 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 41 LSB</td> <td>B6 41 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 10 MSB</td> <td>B6 10 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 42 LSB</td> <td>B6 42 LSB</td> <td></td> </tr> <tr> <td rowspan="8">EQ [MID] control</td> <td rowspan="2">Deck A</td> <td>B6 11 MSB</td> <td>B6 11 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 43 LSB</td> <td>B6 43 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 12 MSB</td> <td>B6 12 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 44 LSB</td> <td>B6 44 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 13 MSB</td> <td>B6 13 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 45 LSB</td> <td>B6 45 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 14 MSB</td> <td>B6 14 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 46 LSB</td> <td>B6 46 LSB</td> <td></td> </tr> <tr> <td rowspan="8">EQ [LOW] control</td> <td rowspan="2">Deck A</td> <td>B6 15 MSB</td> <td>B6 15 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 47 LSB</td> <td>B6 47 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 16 MSB</td> <td>B6 16 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 48 LSB</td> <td>B6 48 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 17 MSB</td> <td>B6 17 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 49 LSB</td> <td>B6 49 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 18 MSB</td> <td>B6 18 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 50 LSB</td> <td>B6 50 LSB</td> <td></td> </tr> </tbody> </table>	SW Name	MIDI message (this unit to computer)		Remarks (dd values)	When SHIFT button is off	When SHIFT button is on	MASTER LEVEL control	B6 0 MSB	B6 0 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 32 LSB	B6 32 LSB		MIC LEVEL control	B6 20 MSB	B6 20 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 52 LSB	B6 52 LSB		MIC EQ control	B6 22 MSB	B6 22 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 54 LSB	B6 54 LSB		AUX LEVEL control	B6 24 MSB	B6 24 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 56 LSB	B6 56 LSB		BOOTH MONITOR control	B6 26 MSB	B6 26 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 58 LSB	B6 58 LSB		TRIM control	Deck A	B6 3 MSB	B6 3 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 35 LSB	B6 35 LSB		Deck B	B6 4 MSB	B6 4 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 36 LSB	B6 36 LSB		Deck C	B6 5 MSB	B6 5 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 37 LSB	B6 37 LSB		Deck D	B6 6 MSB	B6 6 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 38 LSB	B6 38 LSB		HEAD PHONES MIXING control	B6 1 MSB	B6 1 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 33 LSB	B6 33 LSB		HEAD PHONES LEVEL control	B6 2 MSB	B6 2 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 34 LSB	B6 34 LSB		EQ [HI] control	Deck A	B6 7 MSB	B6 7 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 39 LSB	B6 39 LSB		Deck B	B6 8 MSB	B6 8 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 40 LSB	B6 40 LSB		Deck C	B6 9 MSB	B6 9 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 41 LSB	B6 41 LSB		Deck D	B6 10 MSB	B6 10 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 42 LSB	B6 42 LSB		EQ [MID] control	Deck A	B6 11 MSB	B6 11 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 43 LSB	B6 43 LSB		Deck B	B6 12 MSB	B6 12 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 44 LSB	B6 44 LSB		Deck C	B6 13 MSB	B6 13 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 45 LSB	B6 45 LSB		Deck D	B6 14 MSB	B6 14 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 46 LSB	B6 46 LSB		EQ [LOW] control	Deck A	B6 15 MSB	B6 15 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 47 LSB	B6 47 LSB		Deck B	B6 16 MSB	B6 16 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 48 LSB	B6 48 LSB		Deck C	B6 17 MSB	B6 17 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 49 LSB	B6 49 LSB		Deck D	B6 18 MSB	B6 18 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 50 LSB	B6 50 LSB	
SW Name	MIDI message (this unit to computer)		Remarks (dd values)																																																																																																																																																																																																																																																																																																																																																					
	When SHIFT button is off	When SHIFT button is on																																																																																																																																																																																																																																																																																																																																																						
MASTER LEVEL control	B6 0 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 32 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
MIC LEVEL control	B6 20 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 52 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
MIC EQ control	B6 22 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 54 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
AUX LEVEL control	B6 24 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 56 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
BOOTH MONITOR control	B6 26 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 58 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
TRIM control	Deck A	B6 3 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 35 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 4 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 36 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 5 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 37 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 6 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 38 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
HEAD PHONES MIXING control	B6 1 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 33 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
HEAD PHONES LEVEL control	B6 2 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 34 LSB	- - -																																																																																																																																																																																																																																																																																																																																																						
EQ [HI] control	Deck A	B6 7 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 39 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 8 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 40 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 9 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 41 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 10 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 42 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
EQ [MID] control	Deck A	B6 11 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 43 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 12 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 44 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 13 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 45 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 14 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 46 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
EQ [LOW] control	Deck A	B6 15 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 47 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 16 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 48 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 17 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 49 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 18 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 50 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
SW Name	MIDI message (this unit to computer)		Remarks (dd values)																																																																																																																																																																																																																																																																																																																																																					
	When SHIFT button is off	When SHIFT button is on																																																																																																																																																																																																																																																																																																																																																						
MASTER LEVEL control	B6 0 MSB	B6 0 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 32 LSB	B6 32 LSB																																																																																																																																																																																																																																																																																																																																																						
MIC LEVEL control	B6 20 MSB	B6 20 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 52 LSB	B6 52 LSB																																																																																																																																																																																																																																																																																																																																																						
MIC EQ control	B6 22 MSB	B6 22 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 54 LSB	B6 54 LSB																																																																																																																																																																																																																																																																																																																																																						
AUX LEVEL control	B6 24 MSB	B6 24 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 56 LSB	B6 56 LSB																																																																																																																																																																																																																																																																																																																																																						
BOOTH MONITOR control	B6 26 MSB	B6 26 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 58 LSB	B6 58 LSB																																																																																																																																																																																																																																																																																																																																																						
TRIM control	Deck A	B6 3 MSB	B6 3 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 35 LSB	B6 35 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 4 MSB	B6 4 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 36 LSB	B6 36 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 5 MSB	B6 5 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 37 LSB	B6 37 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 6 MSB	B6 6 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 38 LSB	B6 38 LSB																																																																																																																																																																																																																																																																																																																																																					
HEAD PHONES MIXING control	B6 1 MSB	B6 1 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 33 LSB	B6 33 LSB																																																																																																																																																																																																																																																																																																																																																						
HEAD PHONES LEVEL control	B6 2 MSB	B6 2 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																					
	B6 34 LSB	B6 34 LSB																																																																																																																																																																																																																																																																																																																																																						
EQ [HI] control	Deck A	B6 7 MSB	B6 7 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 39 LSB	B6 39 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 8 MSB	B6 8 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 40 LSB	B6 40 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 9 MSB	B6 9 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 41 LSB	B6 41 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 10 MSB	B6 10 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 42 LSB	B6 42 LSB																																																																																																																																																																																																																																																																																																																																																					
EQ [MID] control	Deck A	B6 11 MSB	B6 11 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 43 LSB	B6 43 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 12 MSB	B6 12 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 44 LSB	B6 44 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 13 MSB	B6 13 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 45 LSB	B6 45 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 14 MSB	B6 14 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 46 LSB	B6 46 LSB																																																																																																																																																																																																																																																																																																																																																					
EQ [LOW] control	Deck A	B6 15 MSB	B6 15 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 47 LSB	B6 47 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 16 MSB	B6 16 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 48 LSB	B6 48 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 17 MSB	B6 17 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 49 LSB	B6 49 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 18 MSB	B6 18 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 50 LSB	B6 50 LSB																																																																																																																																																																																																																																																																																																																																																					
30	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">SW Name</th> <th colspan="2">MIDI message (this unit to computer)</th> <th rowspan="2">Remarks (dd values)</th> </tr> <tr> <th>When SHIFT button is off</th> <th>When SHIFT button is on</th> </tr> </thead> <tbody> <tr> <td rowspan="8">COLOR control</td> <td rowspan="2">Deck A</td> <td>B6 27 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 59 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 28 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 60 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 29 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 61 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 30 MSB</td> <td>- - -</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 62 LSB</td> <td>- - -</td> <td></td> </tr> <tr> <td>Deck A</td> <td>96</td> <td>84</td> <td>dd</td> <td>96</td> <td>96</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> </tbody> </table>	SW Name	MIDI message (this unit to computer)		Remarks (dd values)	When SHIFT button is off	When SHIFT button is on	COLOR control	Deck A	B6 27 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 59 LSB	- - -		Deck B	B6 28 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 60 LSB	- - -		Deck C	B6 29 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 61 LSB	- - -		Deck D	B6 30 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 62 LSB	- - -		Deck A	96	84	dd	96	96	dd	OFF=0, ON=127	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">SW Name</th> <th colspan="2">MIDI message (this unit to computer)</th> <th rowspan="2">Remarks (dd values)</th> </tr> <tr> <th>When SHIFT button is off</th> <th>When SHIFT button is on</th> </tr> </thead> <tbody> <tr> <td rowspan="8">COLOR control</td> <td rowspan="2">Deck A</td> <td>B6 27 MSB</td> <td>B6 27 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 59 LSB</td> <td>B6 59 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck B</td> <td>B6 28 MSB</td> <td>B6 28 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 60 LSB</td> <td>B6 60 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck C</td> <td>B6 29 MSB</td> <td>B6 29 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 61 LSB</td> <td>B6 61 LSB</td> <td></td> </tr> <tr> <td rowspan="2">Deck D</td> <td>B6 30 MSB</td> <td>B6 30 MSB</td> <td>0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383</td> </tr> <tr> <td>B6 62 LSB</td> <td>B6 62 LSB</td> <td></td> </tr> <tr> <td>Deck A</td> <td>96</td> <td>84</td> <td>dd</td> <td>96</td> <td>96</td> <td>dd</td> <td>OFF=0, ON=127</td> </tr> </tbody> </table>	SW Name	MIDI message (this unit to computer)		Remarks (dd values)	When SHIFT button is off	When SHIFT button is on	COLOR control	Deck A	B6 27 MSB	B6 27 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 59 LSB	B6 59 LSB		Deck B	B6 28 MSB	B6 28 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 60 LSB	B6 60 LSB		Deck C	B6 29 MSB	B6 29 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 61 LSB	B6 61 LSB		Deck D	B6 30 MSB	B6 30 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383	B6 62 LSB	B6 62 LSB		Deck A	96	84	dd	96	96	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																
SW Name	MIDI message (this unit to computer)		Remarks (dd values)																																																																																																																																																																																																																																																																																																																																																					
	When SHIFT button is off	When SHIFT button is on																																																																																																																																																																																																																																																																																																																																																						
COLOR control	Deck A	B6 27 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 59 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 28 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 60 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 29 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 61 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 30 MSB	- - -	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 62 LSB	- - -																																																																																																																																																																																																																																																																																																																																																					
Deck A	96	84	dd	96	96	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	
SW Name	MIDI message (this unit to computer)		Remarks (dd values)																																																																																																																																																																																																																																																																																																																																																					
	When SHIFT button is off	When SHIFT button is on																																																																																																																																																																																																																																																																																																																																																						
COLOR control	Deck A	B6 27 MSB	B6 27 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 59 LSB	B6 59 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck B	B6 28 MSB	B6 28 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 60 LSB	B6 60 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck C	B6 29 MSB	B6 29 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 61 LSB	B6 61 LSB																																																																																																																																																																																																																																																																																																																																																					
	Deck D	B6 30 MSB	B6 30 MSB	0-16383 When turned fully counterclockwise: 0 / When turned fully clockwise: 16383																																																																																																																																																																																																																																																																																																																																																				
		B6 62 LSB	B6 62 LSB																																																																																																																																																																																																																																																																																																																																																					
Deck A	96	84	dd	96	96	dd	OFF=0, ON=127																																																																																																																																																																																																																																																																																																																																																	

