



Workaround for Mac OS 10.9 not recognizing your DJ equipment

1. Connect DJ equipment to your computer and turn the power on.
2. Open [Finder] and select [Applications] from [Go] on the menu bar.
3. Run [Audio MIDI Setup] in the [Utilities] folder.
4. Ensure that [Audio MIDI Setup] is shown on the menu bar. Then, select [Show MIDI Window] from [Window].



5. [MIDI Studio] window opens up. If you have any issue, a [USB MIDI Device] icon appears.
6. Re-set the Change Configuration drop down from 'Default' to 'New Configuration.'



7. [USB MIDI Device] will be changed to the correct name of the device connected to your Mac.
* An example when DDJ-ERGO is connected to Mac.



* Mac is a trademark of Apple Inc., registered in the U.S. and other countries.

© 2014 PIONEER CORPORATION. All rights reserved.

PIONEER CORPORATION

1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan