

- If an AC adapter is not used, connect this unit to a USB mobile battery or a USB power adapter using the USB cable included with this unit.

❖ Press and hold the "lock" button to unlock the plug while connecting or disconnecting the 30-pin Dock connector and align the arrow mark of the plug with the screen of an iOS device as shown in the figure below.